SYTECH

Nose and Ear Hair Trimmer

SY-NT13

Instructions Manual

WELCOME

Thank you for purchasing the Nose and Ear Hair Trimmer SY-NT13. In order to benefit fully from this product please read the following instructions carefully. Store the instructions manual in a safe place for future reference.

PARTS OF THE SY-NT13

1. Protective cap
2. Nose/Ear hair cutter attachment
3. ON/OFF switch
4. Body
5. Battery compartment lid
6. Attachment for trimming eyebrows, whiskers, moustache or beard

ACCESSORIES

Storage Stand with Mirror

Comb

Oil Bottle

Brush

SAFETY MEASURES

- Use the unit only for the intended purposes as described in this manual.
- Never leave the operating unit unattended.
- Do not use the accessories, which are not included in the set supplied with the unit.
- Switch off the unit when not in use, before replacing/removing the attachments or before cleaning.
- Do not immerse the unit into water or other liquids.
- Do not allow children to use the unit as a toy.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
- Do not use the unit if it has any damages or if the unit malfunctions.
- Do not repair the unit yourself, contact the authorized service center.
- Watch the battery condition. Remove the battery from the battery compartment, if you are not planning to use the unit for a long time.
- This unit is intended for household use only.

Inserting the batteries

- Remove the battery compartment lid by turning it anticlockwise.
- Insert one double “AA” type battery and making sure to follow the polarities.
- Place the lid back on and close firmly.

USE OF THE SY-NT13

The attachment (2) is used to remove hair in the nose or the ears. Upon removing this attachment, place the attachment (6) onto the unit and it can be used to trim eyebrows, whiskers, moustache or beard.

- Remove the cap (1).
- Use the switch (3) to switch on the unit.
- Carefully insert the metal tip of the attachment (2) in the nostril or the ear to cut the hair.
- After use, make sure to switch off the unit (3).

Note: to remove the attachment (2), turn it anticlockwise and pull upwards.
Note: to place the attachment (6), place it and turn it clockwise till it is firmly placed.

- Use the switch (3) to switch on the unit.
- Perform cutting or trimming of eyebrows, whiskers, moustache or beard.
- After use switch off the unit (3).

CLEAN AND CARE

- Remove the battery from the battery compartment
- Wipe the outer surface of the unit with a soft damp cloth; provided that water does not get inside the unit.
- Do not use any chemicals or abrasive liquids to clean the unit.
- Use a brush to clean the blades of the attachment (2)
- Insert the battery back into the battery compartment

SPECIFICATIONS

Nose and ear trimmer
Cuts in a circular motion to facilitate hair removal
Light weight and easy to use
Rubber finish
Detachable head for easy cleaning
On and Off switch
Operates with 1 “AA” -R6 battery (Not included)

The manufacturer reserves the right to change the device’s characteristics without prior notice.

DECLARATION OF CONFORMITY

Manufacturer Name: Satyatrade S. L.
Address: Pol. Ind. La Raya. C/ Guadalquivir, 2.
Camarma de Esteruelas, 28816 Madrid
Tel: 902 430 967
Fax: 91 8864285
NIF: B83254763
Manufacturing country: China
Sytech® SY-NT13 complies with the following directives:

EMC Standard: Directive 2004/108/EC
EN 55014-1:2003
EN 55014-2:1997+A1:2001
EN 61000-3-2:2006
EN 31000-3-3:1995+A1:2001+A2:2005

ROHS standard: 2002/95/EC Restriction of Hazardous Substance

Signed: Ajeet Nebhwani Utamchandani
Sole Administrator